

Golf Cart Maintenance Checklist

Affordable Golf Cart Service | 1-844-844-4070 | affordablegolfcartservice.com

MONTHLY MAINTENANCE

- ☐ Check battery water levels (top off lead-acid cells with distilled water)
- ☐ Clean battery terminals and check for corrosion
- ☐ Check tire pressure and inspect tread for wear
- ☐ Test lights, turn signals, horn, and gauges
- ☐ Inspect brakes for responsiveness and unusual noise
- ☐ Wash the cart and check the body for damage

SEASONAL MAINTENANCE

- ☐ Inspect and tighten all electrical connections
- ☐ Test charger output and inspect charging cables
- ☐ Check brake pads/shoes and adjust brake cables
- ☐ Inspect suspension, steering, and wheel bearings
- ☐ Lubricate moving parts and check for fluid leaks
- ☐ Inspect motor brushes and listen for unusual motor noise

ANNUAL MAINTENANCE

- ☐ Perform a full battery load test on every battery
- ☐ Replace worn brake components and service brake system
- ☐ Inspect and service the motor and speed controller
- ☐ Check and replace tires that are worn or cracked
- ☐ Complete a full multi-point safety inspection
- ☐ Schedule professional service for anything beyond DIY

STORAGE PREP (before long-term storage)

- ☐ Fully charge batteries and disconnect the main connector
- ☐ Clean terminals and apply anti-corrosion protectant
- ☐ Store in a cool, dry place and elevate or inflate tires
- ☐ Top off charge periodically during long storage

Need help? Call Affordable Golf Cart Service at 1-844-844-4070 for expert golf cart maintenance.